



MITRE SLOT BASE

How to Check the Table Saw Blade Runout

Required

- MAG-DRO's Mitre Slot Base
- Six-inch calipers (digital)
- Painters tape
- May need a spacer piece if miter slot is too far from blade





1. With the table saw unplugged and the blade raised to full height, put the Mitre Slot Base and calipers into the miter slot next to one side of the blade.

 Move the depth probe out against the blade (adjust position if necessary) and set the zero.
Note: if your depth probe does not reach the blade, then a spacer is needed.

- 3. Retract calipers rotate blade in small increments to another position and check position with the depth probe.
- 4. Mark and record numbers with painters tape the min and max caliper dimensions.
- 5. If desired, mark the mandrel and radially transfer the min and max dimensions to the mandrel. Put another saw blade in and repeat the process to determine if the dimensions are repeated back to the mandrel.

Patent Pending MAG-DRO, INC. www.mag-dro.com