

MAG-DRO®

MAGNETIC CALIPER BASE

CUTTING AN EXACT WIDTH BOARD

Board width needs to be less than caliper jaws.

REQUIRED

- MAG-DRO's magnetic Caliper Base
- Six-inch calipers (digital)



2. Cut the board a little wider than the final desired measurement.



1. Measure board with the calipers to get an exact width. Note the difference to the desired width.



3. Place caliper and base assembly on the table saw close to the fence, extend depth probe to rest against the fence and set the calipers zero.



4. While applying pressure to the calipers as shown; move the fence towards the blade the desired distance and lock the fence down.

5. Re-cut the board and use the calipers to check for accuracy.

Please note: There are many factors that affect the accuracy of a cut (holding the board secure against the fence, etc).

