

MAG-DRO[®]

MAGNETIC CALIPER BASE

INSTALLATION AND INTRODUCTION

INSTALLATION



1. Loosen thumbscrew
1 ½ turns



2. Slide caliper under
washer



3. Straighten caliper on
Caliper Base
4. Tighten thumbscrew

ADDING DIRECTIONAL ARROWS TO YOUR CALIPER (OPTIONAL)



1. Cut out the arrows and signs
from instructions
2. Apply clear tape over arrows
3. Place arrows per instructions
and trim excess tape

MAKING YOUR CALIPER PERPENDICULAR TO THE FENCE (OPTIONAL)



1. Place caliper and Caliper Base
assembly on table saw close to
the fence
2. Using the 2 bumps on the
Caliper Base opposite the
thumb screw rotate base to
square caliper to the fence

MAG-DRO®

TRY IT OUT AND MOVE YOUR FENCE 0.005"



1. Place caliper and Caliper Base assembly close to the fence (on a cam locking fence place the unit close to the front of the fence due to movement when locking)



2. Push the depth probe up against the fence and set the zero on the calipers



3. Loosen and move the fence 0.005" while applying pressure to the calipers as shown and lock the fence down

U.S. Patent 7,735,237 and Patent Pending
MAG-DRO, INC.
www.mag-dro.com